

Software Update Instruction:

Use this procedure to update the unit's software. You can update the software via a USB storage device.

Updating via a USB storage device is performed by downloading the update file from a computer, reading this file onto a USB storage device then inserting the USB storage device into the USB port on the unit' front panel.

- If an update file is provided on the Pioneer website, download it onto your computer. When downloading an update file from the Pioneer website onto your computer, the file will be in ZIP format. Unzip the ZIP file before saving it on the USB storage device. If there are any files or folders on the USB storage device, delete them.

Important

- DO NOT unplug the power cord during updating.
- When updating via a USB storage device, do not disconnect the USB storage device.

1 Press SETUP.

- The Initial Setup screen is displayed on the main display.

2 Select Option Setting -> Software

- Update -> Start, then press ENTER.

3 To update, press ENTER.

- The display will temporarily disappear, and after about twenty seconds, the update menu will be displayed and update will begin.
- When the update is completed, the unit will automatically reboot.

Software Update messages

File Not Found. : No update file was found on the USB storage device. Store the file in the USB storage device root directory.

Pioneer (HK) Limited - Customer Service Center

Unit 2, 17/F, Vanta Industrial Centre,
21-33 Tai Lin Pai Road,
Kwai Chung.

Tel (852) 3583-3288 Fax (852) 3583-2148