

## Firmware Update Instructions:

### Important Information

All network setting will be reset to the factory default after the update.

Write down these settings before the update as they will needed to set up the network again.

Step 1: Connect your SMA speaker to your wireless network (for set-up instructions, reference the Quick Start Guide that came with your speaker)

Step 2: Access your speaker's Web Control menu by doing the following:

#### Windows 7 or Vista users:

Simply click the Start icon on your Desktop, select "Computer" and then select Network from the list on the left side of your screen. Your SMA speaker will appear as an icon in the explorer menu on the right. Right-click it and select View Device Webpage. The Web Control Menu will open in your default browser.

#### Windows XP Users:

Simply click the Start icon on your Desktop and select My Network.

Click on, Display icons for UPnP devices connected to the network and your speaker will appear as an icon in the explorer menu.

Double-click on the speaker icon and the Web Control Menu will open in your default browser.

#### Safari Users:

Open your Safari browser and click on the Bookmark icon on the upper left side of the screen.

Click on Bonjour List and select your speaker from the list.

Step 3: From the Web Control Menu, check the unit's firmware version, which is listed at the top of the main System Information screen.

Step 4: Download the firmware and change history files. Unzip the file and save it to a place on your computer that you'll remember.

Step 5: From the Web Control Menu, click on Firmware Update and click Start. Within 2 minutes, the firmware update screen will open.

Step 6: Click the Choose File button and find the unzipped file that you just saved on your computer.

Step 7: Click Upload and then click Yes on the confirmation screen.

The update will begin and you can watch its progress from your computer.

Once the update finishes, follow the instructions on your computer and unplug the power cord from your speaker.

Step 8: Now that your speaker is updated, your network settings have been reset and you'll need to reconnect your speaker to your home network.

For set-up instructions, reference the Quick Start Guide that came with your speaker.