

BDP-LX54/BDP-430


About YouTube playback

The YouTube service this product supports is YouTube Leanback.

NOTE

- As of October 2011, the YouTube Leanback access screen is only available in English. For details, see the YouTube Help, for example at <http://www.google.com/support/youtube/>.
- YouTube videos for mobile phones cannot be played.
- It may not be possible to play some YouTube videos.
- Depending on the Internet connection environment, it may not be possible to play YouTube videos properly.
- To access to web contents, this player requires a broadband Internet connection. A contract with an Internet provider is required for a broadband Internet connection.
- Access to content provided by third parties requires a high speed internet connection and may also require account registration and a paid subscription. Third party content services may be changed, suspended, interrupted, or discontinued at any time without notice, and Pioneer disclaims any liability in connection with such occurrences. Pioneer does not represent or warrant that content services will continue to be provided or available for a particular period of time, and any such warranty, express or implied, is disclaimed.

Playback



CAUTION

- Check the following sections of the operating instructions before operating:
 - Connecting to the LAN (10/100) terminal (page 11)
 - Internet Setting (page 21)
 - Communication Setup (page 22)
- Remove any disc from the disc tray when viewing YouTube videos.

1 Display the selection screen.

When the wallpaper is displayed, use **←/→** to select the YouTube logo, then press **ENTER**.

- YouTube can also be selected by pressing **HOME MENU** and selecting [Web Contents] → [YouTube].

2 Select the file and play it.

Use **↑/↓/←/→** to select the file, then press **ENTER**.

- To stop playback, press **HOME MENU**. Playback of the video stops and the Pioneer logo screen (wallpaper) reappears.

BDP-LX54/BDP-430


關於YouTube播放

本產品支援的YouTube服務為YouTube Leanback。

附註

- 截至2011年10月，YouTube Leanback存取畫面僅有英文版。有關詳細資訊，請參閱YouTube Help，範例可至<http://www.google.com/support/youtube/>瀏覽。
- 無法播放用於行動電話的YouTube視訊。
- 本播放機無法播放某些YouTube視訊。
- 視網路連接環境而定，有可能無法正常播放YouTube視訊。
- 若要存取網路內容，本播放機需要寬頻網際網路連線。需與網際網路業者簽訂寬頻網際網路連線的合約。
- 存取由第三方提供之內容需要高速網路連接，也可能需要登錄帳戶及付費訂閱。第三方內容服務可能會隨時在未通知的情況下變更、暫停、中斷或停止，而先鋒對於發生此連接問題一概不負任何責任。先鋒不代表或擔保該內容服務可持續提供或可在特定時間範圍內使用，而所有此類保固，不論明示或暗示皆拒絕承認。

播放



小心

- 在操作前，請檢查下列操作手冊章節：
 - 連接至LAN（10/100）端子（第11頁）
 - Internet Setting（第21頁）
 - Communication Setup（第22頁）
- 觀看YouTube視訊時，請取出碟盤中的碟片。

1 顯示選擇畫面。

顯示底色圖案時，請使用 \leftarrow/\rightarrow 選擇YouTube標誌，然後按**ENTER**。

- 也可按下**HOME MENU**再選擇[Web Contents] → [YouTube]以選擇YouTube。

2 選擇檔案並播放。

使用 $\uparrow/\downarrow/\leftarrow/\rightarrow$ 選擇檔案，然後按**ENTER**。

- 若要停止播放，請按下**HOME MENU**。停止播放視訊且再度出現先鋒標誌畫面（底色圖案）。