



DJM-S11 DEALER DECK

www.pioneerdjhub.com

OVERVIEW



TURN IT UP TO 11: MEET THE DJM-S11 PROFESSIONAL SCRATCH STYLE 2-CHANNEL DJ MIXER REACH THE NEXT LEVEL WITH INNOVATIVE FEATURES, NEVER SEEN BEFORE.

- Raise your game with the DJM-S11. This new professional 2-channel, 4-deck battle mixer brings enhancements to various elements from its predecessor, the DJM-S9, and offers a host of brand-new features to help you perform more freely with Serato DJ Pro or rekordbox.
- When you're scratching and making mash-ups on the fly, every second is priceless. Spend more time focusing on your mix when you play on the DJM-S11 thanks to the mixer's 4.3-inch customizable touch screen, which has all the information you need. Browse tracks, check on playback positions and waveforms, and dynamically change the texture of the music by moving your finger across the Touch FX screen. With Touch MIDI, you can even trigger functions in your DJ software. All this means you can stay focused and keep your eyes on the mixer during your performance.
- Packing more sounds into your sets can make the difference between a good crowd reaction and a great one. In a battle, it could even push you up the podium from second to first place. You can play up to four tracks at once on the DJM-S11 thanks to Deck 3/4 Control. The additional decks appear on the touch screen with a selection of controls so you can browse and load tracks, adjust EQs, set loops, trigger Hot Cues, and more. If you're using Serato DJ Pro, with Deck Move you can move tracks from deck 1 to 4 and deck 2 to 3 without a break in the music – enabling you to free up the main decks and prepare to drop in your next track. And you can switch on Dual Deck control to use one fader, knob, or control vinyl to manipulate the tracks loaded to decks 1 and 3 or 2 and 4. This means you can scratch two tracks at once, add effects, or adjust their volume simultaneously.
- As well as a different look, you'll also notice enhancements in the way the DJM-S11 feels compared to its predecessor. Its Performance Pads are larger and the MAGVEL FADER PRO has been strengthened to give you more stability when you're scratching. Spotted some new controls? There's a host of fresh features (which you can read more about below) including Smooth Echo, a new effect that you can automatically engage when you move the faders or hit the pads you've assigned as triggers. Sound quality has been improved too, with clear, powerful audio that reflects every nuance of your performance.
- As a DJ, you're unique – and so is your setup. The DJM-S11 has been specially designed so you can effortlessly play the way you like. Its built-in USB hub enables you to directly connect with CDJs and the DDJ-XP2. It's also compatible with Serato DJ Pro and rekordbox straight out of the box with no need for license keys, so simply plug in and play. Want to use another DJ application? Every fader, knob, and button is fully MIDI mappable.
- If you want to add a distinctive look to your setup, choose the DJM-S11-SE. This special edition mixer inherits style elements from the classic DJM-909, which was released in 2004 and remains a favorite with purists to this day.

KEY FEATURES OF THE DJM-S11

- 4.3-inch touch screen with high frame rate:** Reference tracks and settings, and trigger FX Save the priceless seconds it takes to switch your gaze from your mixer to your laptop and back again. The high-frame-rate color touch screen on the DJM-S11 shows everything from waveforms to BPM information so you can stay in the zone and concentrate on what your hands are doing or look up to see how the crowd is reacting to your performance. It's perfect for browsing tracks and it's customizable, so you can set it to your preferred layout style. Ready to express yourself in new ways? Switch to the Touch FX screen and you can control two effects at the same time by tracing one finger across the surface while the other hand is scratching with the crossfader or finger drumming on the Performance Pads. And in the FX Setting screen, you can save four sets of effect types and parameters, then instantly call them up in different scenarios, e.g. when you're battling, mashing up tracks, or playing a club set. Touch MIDI offers four pages of presets that enable you to control functions in your DJ software without touching your laptop. The controls can also be custom MIDI mapped, enabling you to set things up to suit your style. Ready to express yourself in new ways? Switch to the Touch FX screen and you can control two effects at the same time by tracing one finger across the surface while the other hand is scratching with the crossfader or finger drumming on the Performance Pads. And in the FX Setting screen, you can save four sets of effect types and parameters, then instantly call them up in different scenarios, e.g. when you're battling, mashing up tracks, or playing a club set. Touch MIDI offers four pages of presets that enable you to control functions in your DJ software without touching your laptop. The controls can also be custom MIDI mapped, enabling you to set things up to suit your style.
- Industry-first Smooth Echo:** Trigger the echo automatically with a fader/pad you choose Assign the Smooth Echo effect to your choice from a selection of controls, e.g. a fader or pad. Then, when you turn on Smooth Echo with its dedicated button, the echo will be triggered as soon as you move the relevant control. With changeable parameters for the effect, this new feature – never seen before on a DJ mixer – gives you the chance to create sounds while you're scratching or finger drumming that were previously difficult to achieve.
- World's first Deck 3/4 Control:** Play up to four tracks and easily create live mashups Want to pack more sounds into your sets? Play up to four tracks simultaneously thanks to Deck 3/4 Control, a never-seen-before feature that offers two extra decks, accessible via the touch screen. These additional decks include a range of controls such as EQs, Hot Cues, pitch bend and more, making it easier than ever to create live mashups of multiple tracks. When you use Serato DJ Pro, you'll have access to two powerful additional features. With Deck Move, you can reassign tracks from deck 1 to 4 and deck 2 to 3 without interrupting the sound. This enables you to free up the main decks so you're ready to start playing your next track or scratching a new sample. And when you switch on Dual Deck control, you can adjust the volume and effects parameters for two decks at the same time, or scratch two tracks simultaneously.
- Enhanced design, larger pads, and low latency:** Perform more intuitively than ever easily find your way around the clean design and feel the mixer respond to your performance. The load button is larger than the one on the DJM-S9 and ideal for quicker track selection. Latency is minimal and the eight Performance Pads are bigger too, making them easier to hit in energetic battles.

KEY FEATURES OF THE DJM-S11

5. **Scratch Bank:** Rapidly access your sounds from Serato DJ Pro With the new pad mode Scratch Bank, you can instantly load scratch samples from four banks that you've assigned in Serato DJ Pro by simply tapping a pad. You can load from a specified start point too – handy if you want to use this feature to drop in full tracks during a routine. Activate Combo Pad mode in Serato DJ Pro to use up to four different pad modes simultaneously (two modes per channel, four pads per mode) and combine more features.
6. **High-quality audio:** Rock the crowd with crystal-clear sound, faithfully reflecting every nuance of your performance
Under the surface of the DJM-S11 is a host of premium audio technology that ensures every detail of your performance is heard loud and clear. With studio-quality 64-bit mixing and dithering processing inside the DSP, plus a low-jitter clock circuit and 32-bit high-quality D/A converter in the master output section, the mixer inherits a high-density, raw sound from the industry-standard DJM-900NXS2.
7. **Improved MAGVEL FADER PRO:** Feel supported when you scratch
If you liked the crossfader on the DJM-S9, you'll love the improved version on the DJM-S11. We've enhanced the feeling of the MAGVEL FADER PRO and boosted the rigidity of the knob mounting axis in the vertical direction by 30 percent. This means you can scratch with more confidence, while the tougher coating around the crossfader area reduces wear to the top panel – preserving your mixer's fresh look.
8. **22 built-in effects including new Beat FX:** Add texture to your tracks
Spice up your sets with all 15 Beat FX from the DJM-S9, plus seven new ones including Channel Fader Pitch and Helix. You can instantly trigger the effects saved in four FX Banks and edit them via the touch screen whenever you like. While you're using one of these effects, you can also trigger up to six more from your DJ software to create sounds your crowd has never heard before.
9. **Direct USB connections: Ditch your hub**
There's no need to use an external USB hub with the DJM-S11. Simply plug your DJ controllers and other devices into the dual USB-A ports to play with them. You can hook up two CDJs to use HID mode and the mixer includes two USB-B ports so you can plug in two laptops simultaneously for smooth DJ changeovers.
10. **Plug and play and MIDI mapping: Use Serato DJ Pro or rekordbox for free**
The DJM-S11 is a Hardware Unlock device for rekordbox – giving you free use of Performance mode – and it enables DVS control when you connect it to a computer running the application. You can also enjoy plug-and-play use of Serato DJ Pro for free – there's no need to activate a license key. A voucher for the Serato Pitch 'n Time DJ Expansion Pack is included, which enables, key shifting and key syncing with perfect audio quality. And with advanced MIDI mapping you can assign every button and knob to control various functions in the DJ software, enabling you to perform however you want.

DESIGN





















TARGET USERS




MAIN TARGET USERS: THE TOP40 DJ'S WHO PARTICIPATES IN BATTLE
SUB-TARGET AUDIENCE: TOP40 DJ'S PLAYING IN THE CLUB



MAIN TARGET USERS: THE TOP40 DJ'S WHO PARTICIPATES IN BATTLE
SUB-TARGET AUDIENCE: TOP40 DJ'S PLAYING IN THE CLUB



Professional scratch DJs



Club (Open format / Top40 DJs)





Competition / Battle DJs


FEATURES

LAYOUT









UNIVERSAL DJ APPLICATION SUPPORT



Plug in and play and full MIDI mapping: Use Serato or rekordbox with the DJM-S11. Unlock both Serato DJ Pro and rekordbox when you connect it to a computer running either application – you don't need to activate a license key to start DJing. The DJM-S11 is recognised as a dongle allowing users to use the app without having to enter a license key.


A voucher for the Serato Pitch 'n Time DJ Expansion Pack is included, which enables features such as Pitch Play, and Key Shift. To use FLIP, DJ's will need to purchase a license.

The mixer is fully MIDI mappable, you can assign every button, and knob to control various features and functions in other types of DJ software, enabling you to perform however you want.



UPDATED POINTS FROM THE DJM-S9

- 4.3-inch touch screen for quick-mixing
- The TRIM, ISOLATOR and FILTER are the same array as the industry standard DJM-900NXS2.
- Large LOAD button that can execute the load quickly and accurately.
- Each channel has an independent PAD mode that allows for a wide variety of performances.
- The large PAD can be used for quick and accurate tapping and continuous tapping.



FEATURES




4.3-INCH TOUCH SCREEN WITH HIGH FRAME RATE: REFERENCE TRACKS AND SETTINGS, AND TRIGGER FX

The DJM-S11 has a 4.3-inch touch screen. By checking waveform information and browsing status quickly and accurately on the display to hand, you can quickly and reliably play without moving your eyes to a PC. You can customise the content you display according to your playstyle.

The high frame rate waveform display allows you to accurately check the playback position of the song, the BPM and beat deviation between the two tracks that are to be mixed in order to support a quick mix.



TOUCH SCREEN MENU DISPLAY LAYOUT



HIGH-QUALITY AUDIO: UNDER THE SURFACE OF THE DJM-S11 IS A HOST OF PREMIUM AUDIO TECHNOLOGY THAT ENSURES EVERY DETAIL OF YOUR PERFORMANCE IS HEARD LOUD AND CLEAR.

By using studio-quality 64-bit mixing and dithering processing inside the DSP, it reproduces a high-density, raw sound at a higher resolution than ever before. In addition, a low jitter clock circuit and ESS Technology's 32bit high quality D/A converter are used in the MASTER output section.

The result is a crisp sound quality that faithfully reproduces the original sound at high resolution. These quality improvements have resulted in high sound quality reminiscent of the DJM-900NXS2, the club standard DJ mixer, and a sound quality that faithfully reproduces the performance.



BUILT-IN USB HUB - FOR CONNECTING CDJS AND CONTROLLERS WITHOUT HAVING TO PREPARE A SEPARATE EXTERNAL USB HUB.

The DJM-S11 is equipped with a USB hub (type A port) for connecting CDJs and controllers at the same time by directly connecting devices such as CDJs, controllers, and other devices connected to a PC via the USB terminal to the mixer.

This takes away the need to prepare a separate external USB hub. The need for troublesome preparations, and equipment issues should therefore be reduced.



BUILT IN USB HUB

BUILT-IN USB HUB - FOR CONNECTING CDJS AND CONTROLLERS FOR VARIOUS DIFFERENT SET UPS

ON RELEASE OF THE DJM-S11, SERATO HID CONTROL WITH THE CDJ-3000 IS NOT YET SUPPORTED. THERE ARE PLANS TO SUPPORT VIA UPDATING THE CDJ-3000, HOWEVER THIS IS TBC

Blue - USB Cable
 Back - RCA Cable



PERFORMANCE PADS: THE DJM-S11 IS EQUIPPED WITH 16 LARGE 26MM X 22MM (W X H) MULTI COLOURED PERFORMANCE PADS FOR SMOOTHER OPERATION DURING PERFORMANCES.

DJ's now have the option to select different PAD MODE functionalities on channels 1&2.

Holding shift and pressing down on the top row of pads will give users extra performance modes, the same as you would find on some of our popular Midi controller range.

This includes Hot Cues, Roll, Saved Loops, Sampler, Pitch Play, Slicer Loop, Saved Flip and new feature Scratch Bank.



COMBO PAD MODE - TWO PAD MODES CAN BE OPERATED AT THE SAME TIME, WHICH REDUCES THE FREQUENCY OF MODE SWITCHING AND ALLOWS FOR QUICK OPERATION.



When two pad modes are pressed at the same time, the two modes are set to 4 pads each.

Combination example below on channel 1 you can select the hot cues on the first row (4 performance pads) and then on the bottom row below you can select the loop roll (4 performance pads) also, on channel 2 you can select in the same way, the sampler pads and hot cue pads all at the same time during a performance.



SERATO FEATURE: WITH THE NEW PAD MODE SCRATCH BANK, YOU CAN INSTANTLY LOAD SCRATCH SAMPLES FROM FOUR BANKS THAT YOU'VE ASSIGNED IN SERATO DJ PRO BY SIMPLY TAPPING A PAD.



DJ's can scratch the sample sound source assigned to the Sampler slot. Load your favourite scratch samples from the SCRATCH BANK into a DECK for quick scratch during performances.

Users can find this new feature that works with Serato by pressing the shift and sampler button on the DJM-S11. Simply just press one of the empty pads and the track is now loaded to the sampler scratch pads. This feature lets you store your scratch samples or track to quick scratch for performances.

If you open up Serato, on the top of the page, where the sampler button is located, on the right, is the scratch bank tab. Clicking this button will open up the tab. You can load your samples in manually and select the cue point of where you would like to scratch on the track. You can store up to 32 samples using the 4 bank tabs in Serato and access them via the parameters on the DJM-S11.



SCRATCH BANK

PARAMETER 1 MIN MAX PARAMETER 1
 PARAMETER 2 PARAMETER 2
 HOT CUE ROLL SAVED LOOP SAMPLER ROLL SAVED LOOP SAMPLER
 PITCH PLAY SLICER LOOP SAVED FLIP SCRATCH BANK PITCH SLICER LOOP SAVED FLIP SCRATCH BANK


You also have the ability to go back to the previously loaded track by holding down the shift + PAD




SMOOTH ECHO - BY PRESSING THE SMOOTH ECHO ON THE DJM-S11, THIS WILL AUTOMATICALLY ACTIVATE AND TRIGGER AN ECHO FX ON YOUR ASSIGN SOURCE.

Trigger the echo automatically with a fader/pad your choose Assign the Smooth Echo effect to your choice from a selection of controls, e.g. a fader or pad.

when you turn on Smooth Echo with its dedicated button, the echo will be triggered as soon as you move the relevant control. With changeable parameters for the effect, this new feature – never seen before on a DJ mixer – gives you the chance to create sounds while you're scratching or finger drumming that were previously difficult to achieve.



By pressing and holding down the SMOOTH ECHO button this allows a shortcut to the screen settings.



THE DJM-S11 HAS 22 BEAT EFFECTS, INCLUDING 7 NEW TYPES OF FX'S THAT ARE BUILT INTO THE MIXER. THIS ALLOWS FOR A GREATER VARIETY OF PERFORMANCE EXPRESSION THAN EVER BEFORE.


New Beat effects:

- DUCKING ECHO Echo effect is applied when the fader mutes.
- ECHO OUT - Fade out while applying the ECHO effect.
- HELIX - The input sound is recorded and the recorded sound is set. The output is repeated according to the temporal parameters.
- KILL - The output sound is mute.
- ONE-SHOT SPIN - adds the effect of a high-speed reverse rotation of the input sound being played back once
- ONE-SHOT BREAK - Gradually slow down the playback speed of the input sound, and Add one final stopping effect.
- FADER PITCH - The pitch changes during playback in conjunction



IT IS NOW POSSIBLE TO COMBINE ONE BEAT EFFECT, AND SIX DJ SOFTWARE EFFECTS AT THE SAME TIME.

Multiple FX's can be used simultaneously by pressing the FX SELECT at the same time (maximum: 1 built-in effect + 6 DJ software effects)




1 Beat FX



6 DJ software FX

MAGVEL FADER PRO - FROM THE HIGHLY EVALUATED MAGVEL FADER PRO OF THE DJM-S9, FURTHER IMPROVED PERFORMANCE AND DURABILITY HAS BEEN IMPLEMENTED

- Improved vertical rattling by about 30%.
- Improved durability of shaft breakage.



Coating of the crossfader and PAD periphery with improved peeling resistance gives better durability against paint peeling caused by heavy operation.



FEATURES

SCREEN LAYOUT




4.3-INCH TOUCH SCREEN - INTUITIVE CLEAR LAYOUT TO ACCESS FEATURES.


The "Quick Mix Display" allows the DJ to quickly and reliably ascertain the status of the mixer, allowing DJ to play from one performance to the next.




BROWSE screen




Waveform screen




Deck3 Control screen




Deck4 Control screen



Touch FX screen




FX bank screen



Touch Midi screen

BROWSE SCREEN - QUICKLY SELECT SONGS FROM PLAYLISTS WITHOUT MOVING YOUR EYE LINE TO THE PC.

Users will have two view options available in browse selection, 1 or 2 line option, and 3 font size options. This can be located in the Utility



Line tracks option

Large

Medium

Small


TRACK BPM INFO



SORT BUTTON OPTION


Display of music information LOADED to DECK. DJ's can select a song while checking the BPM and key.

WAVEFORM - THE DISPLAY ON THE SCREEN ALLOWS THE DJ TO QUICKLY AND RELIABLY GRASP THE PLAYBACK STATUS AND PLAY ONE PERFORMANCE AFTER ANOTHER.



ZOOM IN/OUT OF WAVES


By holding the shift button and pressing the middle of the screen on the DJM-S11 you can zoom in and out of the waves.




DECK 3&4 - PLAY UP TO FOUR SOUNDS SIMULTANEOUSLY BY OPERATING DECK 3 AND DECK 4 WITH A TOUCH DISPLAY.

It is now possible to play using four tracks with a 2CH mixer without touching a laptop. The "DUAL DECK CONTROL" allows you to adjust the volume "DECK MOVE", which moves a track loaded in a deck to another deck without stopping the playback of the track.

This makes it possible to perform a variety of original mash-up performances that make full use of the four tracks. In addition, basic deck and mixing operations such as song loading, playback, HOT CUE, and TRIM adjustments can also be performed on the touch display.



DECK 3&4 - PLAY UP TO FOUR SOUNDS SIMULTANEOUSLY BY OPERATING DECK 3 AND DECK 4 WITH A TOUCH DISPLAY.




DECK 3&4 - FOUR SCREENS FOR DIFFERENT MODES.

Screen Select




Select different functionalities options

Simple Mode




Simple Mode to operate basic functions of the deck.

Hot Cue Mode




Access and operate hot cues.

Mixer Mode



Adjust volume (mixer settings), headphone cue and channel fader.

Mash Up Mode



To move tracks and dual control for mash up performances.

DECK 3&4 - "DECK MOVE" TO MOVE A SONG LOADED ON 1/2DECK TO 3/4DECK,"DUAL DECK" FOR SIMULTANEOUS CONTROL OF TWO DECKS.

DECK MOVE

TAKE CONTROL OF THE TRACK ON THE CHANNEL

By holding down SHIFT & double tapping LOAD You can also use DECK MOVE

Move a track loaded into DECK2 to DECK3 (or DECK2 to DECK4)

DECK MOVE DECK2 -> DECK3

CH1 turntable, crossfader, CH fader, etc. to control DECK1 and DECK3 simultaneously (or DECK2 and DECK4)

DUAL DECK

DECK 3&4 - EXAMPLE.

1. MIX DECK 1 AND DECK 2

Deck 1 Track A

Deck 2 Track B

2. MOVE A TRACK BY DECK MOVE

DECK MOVE DECK2 -> DECK3

Deck 1 Track A

Deck 3 Track B

3. LOAD A TRACK INTO DECK 2 AND MIX DECK1 +DECK3 AND DECK2

LOAD

Deck 1 Track A

Deck 3 Track B

Deck 2 Track C

4. TURN ON THE DUAL DECK

DUAL DECK

Deck 1 Track A

Deck 3 Track B

CAN BE OPERATED SIMULTANEOUSLY

5. DECK 1 AND DECK3 WITH ECHO AND FADE OUT

BOTH DECK1 AND DECK3 OVERLAY ECHO FX


Deck 1 Track A

Deck 3 Track B

Deck 2 Track C

FX BANK - SELECT EFFECTS INSTANTLY AND RECALL THEM TO THE FX BANK SETTINGS OR DIFFERENT PERFORMANCES.

Quick effect performance by instantly recalling various effect settings. "FX BANK"



RECALLING SAVED SETTINGS


SAVE A SETTING

FX BANK DISPLAY

FX Bank Call - Users can change the FX's they would like to use and then save them in one of the four FX bank call's, (by selecting bank save whenever they make any changes) This will help users access multiple different FX settings for different routines in battles and performances.


FX Bank Call: On the very top of the FX bank page you can see A B C D, this is where users bank FXs are saved and stored which they can access in performances and edit.

FX BANK - CHOOSE DIFFERENT EFFECT AND ASSIGN THEM TO THE HARDWARE BUTTONS ON THE DJM-S11. YOU CAN RECALL DIFFERENT FX SETTING DEPENDING ON YOUR PERFORMANCE BY SAVING THEM IN THE FX BANK.



FX FILTERS.


Filter knobs – by clicking on the filter icon you can manually change the hardware filter rotary knob to a different FX and then save them to the FX Bank call.



RECALLING SAVED SETTINGS

FX FILTER

RESONANCE LEVEL - GIVES YOU MORE DEPTH TO THE FX



By clicking on the filter icon you can manually change the hardware filter rotary knob to a different FX, you can select

- Filter
- Noise
- Pitch
- Dub Echo
- Wide Filter

TOUCH FX- BFX AND CFX CAN BE CONTROLLED BY THE TOUCH SCREEN AT THE SAME TIME.


Pressing CH1 and CH2 button will indicate what channel the FX is to be activated on. Pressing the settings button opens the page where you can select either a preset FX or selected FX.

Preset FX




Select 2 effects from a preset.

Selected FX



Operate the TOUCH FX by selecting a BFX or CFX and combine with the different effects from the filter pot.



Selected FX





Operation mode allows you hold the fx on a position of the screen without having to press the screen.

TOUCH MIDI - THE TOUCH MIDI SCREEN ALLOWS YOU TO CONTROL VARIOUS FUNCTIONS OF THE DJ SOFTWARE WITHOUT HAVING TO USE THE LAPTOP.

Users can quickly operate various functions on DJ software platforms such as Serato DJ PRO and rekordbox from the touch display without having to touch the PC. DJ's can also assign favourite functions to the buttons on the TOUCH MIDI so that the mixer can perform all the operations they need to perform their routines. This feature is fully midi mappable.

Four templates are available to use



COMPARISON



Manufacturer		Pioneer DJ	Pioneer DJ	Rane	Rane
Model		DJM-S9	DJM-S11	72	72 MK2
Image					
Price		€1,699	€1999	€1899	€1999
Product size	Product size Depth	379mm	452.2	424mm	445mm
	Product size Width	267mm	267mm	267mm	284mm
Weight	Weight	4.6kg	5.4kg	5.46kg	5.46kg
Deck	4DECK touch control	x	✓	x	x
Pad Mode	SCRATCH BANK	x	✓	x	x
	Independent PAD MODE for each channels	x	✓	✓	✓
	PAD size	20 X 20	22 X 26	21 x 21	21 x 21
	Combo Pad Mode	x	✓	x	x
	Audio latency	6.9ms	6.9ms	10.18ms	TBC
FX	Simultaneous use of multiple FX	x	✓	✓	✓
	Separate FX for each CH	x	x	✓	✓
	SMOOTH ECHO	x	✓	x	x
Display	Waveform-display	x	✓	✓	✓
	TEMPO Indication	x	✓	✓	✓
Midi	ALL UI MIDI REMAPPING	x	✓	x	x
Cross fader	FEELING ADJUST	✓	✓	Disassemble and adjust	✓
USB hub	USB HUB (A terminal x 2)	x	✓	✓	✓

Pioneer DJ has made reasonable efforts to ensure the accuracy and reliability of this information. However we cannot guarantee the accuracy of the information provided. It is provided 'as is' without any warranty of any kind..

Manufacturer		Pioneer DJ	Pioneer DJ	Rane	Rane
Model		DJM-S9	DJM-S11	72	72 MK2
Image					
Price		€1,699	€1999	€1899	€1999
Screen Display	Display size	1.39inch x 2	4.3 inch	4.3 inch	4.3 inch
	Display resolution	192x64	480 x 272	480 x 272	480 x 272
	Touch screen	x	SINGLE TOUCH	MULTI TOUCH	MULTI TOUCH
	Latency from touch operation to display	x	61ms	85ms	TBC
	touch operation latency	x	20ms	40ms	TBC
	Frame rate	x	30FPS	20FPS	TBC
	Support Language	1	18	1	1
	Font Size	1	3	1	1
	WAVEFORM	x	✓	✓	✓
	BROWSE	x	✓	✓	✓
	DECK3/4 CONTROL	x	✓	x	x
	TOUCH MIDI	x	✓	x	x
TOUCH FX	x	✓	✓	✓	

Pioneer DJ has made reasonable efforts to ensure the accuracy and reliability of this information. However we cannot guarantee the accuracy of the information provided. It is provided 'as is' without any warranty of any kind..

Manufacturer		Pioneer DJ	Pioneer DJ	Rane	Rane
Model		DJM-S9	DJM-S11	72	72 MK2
Image					
Price		€1,699	€1999	€1899	€1999
DJApp	Bundle DJApp	SeratoDJ Pro	SeratoDJ Pro rekordbox	SeratoDJ Pro	SeratoDJ Pro
	Supported DJ App	SeratoDJ Pro rekordbox	SeratoDJ Pro rekordbox	SeratoDJ Pro	SeratoDJ Pro Traktor Virtual DJ
Input / Output	USB TypeB	2	2	2	2
	USB TypeA	x	2	2	2
	FOOT SW	x	x	YES	YES
	AUX GAIN CHANGE	x	Utility	NO	NO
Mic	TYPE	XLR (COMBO)	XLR (COMBO)	XLR x2 (COMBO)	XLR x2 (COMBO)
	MIC EQ	2 band	2 band	1(TONE)	1(TONE)
Audio	ADC - LINE / PHONO	120dB/24bit	120dB/24bit	120dB/24bit	114dB/24bit
	DAC - MASTER	117dB/24bit	122dB/32bit	120dB/24bit	114dB/24bit
	Master, Booth, Output ATT	x	✓	NO DATA	TBC
	Audio latency (DVS)	10.77ms	11.34ms	12.74	TBC
Sound Quilty	64 - bit digital signal processor	x	✓	TBC	TBC
	Dithering technology	x	✓	TBC	TBC

Pioneer DJ has made reasonable efforts to ensure the accuracy and reliability of this information. However we cannot guarantee the accuracy of the information provided. It is provided 'as is' without any warranty of any kind..

SPECIFICATION



Supported software		Rekordbox Serato DJ Pro
Frequency Response		20 Hz – 20,000 Hz (USB, LINE, MIC, AUX)
S/N Ratio	USB	115 dB
	LINE	105 dB
	PHONO	90 dB
	AUX LINE	96 dB
	MIC	80 dB
Total Harmonic Distortion	USB	0.003%
	LINE	0.005%
	PHONO	0.017%
Input / Output Terminals	Inputs	LINE x 2 (RCA) PHONO x 2 (RCA) AUX x 1 (RCA) MIC x 1 (XLR & 1/4 inch TRS jack)
		Outputs
	USB	
	Power	AC 100-240 V, 50 Hz / 60Hz
Maximum Dimensions		W: 267mm D: 466.1 H: 107.9mm
Weight		5.2kg
Accessories		Power cable USB cable Fader Cushion Serato DJ Pro EXPANSION PACK VOUCHER (PITCH 'N TIME DJ) Certificate of Guarantee Instruction Manual (Quick Start Guide)"

<p>Compatible software</p>	<p>The DJM-S11 supports PLUG&PLAY, which allows you to connect your Serato DJ PRO rekordbox and use it right away, recognising it as a dongle between Serato DJ and rekordbox and allowing you to use the app without having to enter a license key. Also included is the Serato DJ Pro EXPANSION PACK VOUCHER (PITCH 'N TIME DJ). You can use the PITCH 'N TIME DJ by entering the license key.</p>
<p>Accessories</p>	<p>Power cable USB cable Fader bumper A × 4 Fader bumper B × 2 Warranty (for some regions) Precautions for Use Serato DJ Pro EXPANSION PACK VOUCHER Please note: Control Vinyl is not included in the package. If you want to use a DVS system, you need to purchase it separately.</p>

SUMMARY



PR DATE : 15th October - 8am - UK

SRP : €1999

KEY FEATURES

- 4.3-inch customisable touch screen screen
- Deck 3/4 control - You can play and control up to four tracks or samples at once via the DJM-S11 without the need to use the laptop.
- Smooth Echo - Automatically trigger the echo FX and assign to different functionalities e.g. crossfader or pads.
- USB hub - The DJM-S11 has two dual USB ports to connect USB devices and CDJ's
- Scratch Bank - Sampler scratch, have quick access to your scratch samples from the performance pads. (Serato only)
- Touch Midi - Customise and map functions directly from the DJM-S11

OVERVIEW

Raise your game with the DJM-S11. This new professional two-channel, four-deck battle mixer brings enhancements to various elements from its predecessor, the DJM-S9, and offers a host of brand-new features to help you perform more freely with Serato DJ Pro, rekordbox



PR DATE : 15th October - 8am - UK

SRP : €2099

KEY FEATURES

- 4.3-inch customisable touch screen screen
- Deck 3/4 control - You can play and control up to four tracks or samples at once via the DJM-S11 without the need to use the laptop.
- Smooth Echo - Automatically trigger the echo FX and assign to different functionalities e.g. crossfader or pads.
- USB hub - The DJM-S11 has two dual USB ports to connect USB devices and CDJ's
- Scratch Bank - Sampler scratch, have quick access to your scratch samples from the performance pads. (Serato only)
- Touch Midi - Customise and map functions directly from the DJM-S11

OVERVIEW

A Special edition version of the new battle mixer, the DJM-S11-SE, incorporates aesthetics from the classic DJM 909 unit so you can combine the latest tech with timeless style.





THANK YOU

www.pioneerdjhub.com